

Barton

Living

4.5' ARTIFICIAL CHRISTMAS TREE

ITEM # 93001



OWNER'S MANUAL AND SAFETY INSTRUCTIONS

SAVE THIS MANUAL. KEEP THIS MANUAL FOR SAFETY WARNINGS, PRECAUTIONS, ASSEMBLY, OPERATION, INSPECTION, MAINTENANCE AND CLEANING PROCEDURES. WRITE THE PRODUCT'S SERIAL NUMBER ON THE BACK OF THE MANUAL, OR THE MONTH AND YEAR OF PURCHASE IF PRODUCT HAS NO SERIAL NUMBER

FOR QUESTIONS, PLEASE CALL CUSTOMER SERVICE: 909.628.4900

SAFETY INFORMATION

WARNING

Read all safety warnings and instructions. Failure to follow the warnings and instructions may result in injury and/or property damage. Save all warnings and instructions for future reference.

The warning and safety instructions in this manual are not meant to cover all possible conditions and situations that may occur. Common sense, caution and care must be exercised when operating or cleaning tools and equipment. Always contact your dealer, distributor, service agent or manufacturer about problems or conditions you do not understand before operating the product.


- Do not leave product unattended while plugged in.
- For Indoor or Sheltered Outdoor Use Only. Product may be used outdoors only where protected from falling rain, snow, or sleet and protected from the elements.
- Do not place near gas or electric heaters, radiators, fireplaces, candles, or other similar sources of heat or open flames.
- Place on a level, hard, flat surface: do not place where tree is likely to wobble due to uneven floors or thick carpeting.
- After assembling the tree and adding decorations, make sure the tree is stable. If tree is not stable, shift the weight of the decorations, and use support wires to walls and/or window frames (make sure they are secure also).
- Do not use candles on this tree.
- Do not overload extension cords or power strips, see ratings on those devices and check the rating label of the product for compatibility.
- Do not store this tree in a damp area, or in an area where the temperatures exceed 100° F.
- To avoid risk of fire, burns, personal injury and electric shock it should not be played with or placed where small children and pets can reach it.
- This product is equipped with non-replaceable type lamps.
- Do not attempt to replace the lamps as that will cause damage to the product.
- Do not connect anyother light strings or accessories to this tree.
- Use only with the adaptor power supply that was provided with this product.
- If the adaptor power supplyis cracked or broken, do not use product.
- When used outdoors, only use outdoor extension cords and outlets that are rated for outdoor use and connect only to GFCI protected outlets.

PARTS LIST AND ASSEMBLY

PARTS INFORMATION

A. TREE UPPER HALF

B. TREE BOTTOM HALF AND
BASE




ASSEMBLY

1. Carefully remove all pieces from the box and lay out parts flat on the floor. Carefully remove all protective wrapping from the parts. Before beginning tree assembly please make sure all carton contents are present. A complete listing and diagram of contents are listed on above. Do not attempt to assemble the tree if any parts are missing or damaged. Please contact our customer service department for replacement parts prior to returning to store.

2. Insert tree top (A) into the tree bottom (B). Make sure it is secured in place.

3. Once the tree is set up, the branches will need to be fluffed up. Gently lift the fronds on each branch from the bottom up. For a fuller look, spread each frond side to side and outward.

4. Plug the adaptor into a 110V-125V AC wall receptacle to turn the lights on.




TROUBLESHOOTING

WARNING: To reduce the risk of electric shock and personal injury.

- a) Unplug the electrical portion of this product before trouble shooting the electrical portion of this product and inspect product carefully.
- b) Lights are non-replaceable do not attempt to replace.
- c) Do not connect any other product or device to the connectors or adaptor power supply on this tree.
- d) Use only with the adaptor power supply that was provided with this product.

If the Lights are Not Connected to the Adaptor

1. Locate the male connector at the bottom of tree Section (1) and align matching tabs on the insides of the connector and the female end of the adaptor power supply. Secure the connection by tightening the collar on the connector. See Figure 5.



If ALL of the Tree Lights are Off or Not Working:

1. Make sure the lights are connected to the adaptor power supply.
2. Make sure the adaptor power supply is plugged into a 110V-125V AC outlet.
3. Check to see if there is power to the outlet. Make sure that a switch controlling the outlet is not turned off and is not connected to a dimmer switch. This item will not work on a dimmer controlled outlet.
4. If used on a timer controlled outlet, make sure the timer is rated for use with compact fluorescent bulbs (CFL) or LED bulbs, if not, use a different circuit or outlet.
5. If installed on a GFCI circuit or outlet, reset the GFCI in case it activated.

If One or More Bulbs are Not Working:

This tree has long life LED non-replaceable bulbs, it is ok to leave the non-functioning bulb in the set and continue to use the tree. Do not attempt to replace the bulbs.

STORAGE Make sure the tree electrical plug is removed from the electrical outlet or any other receptacle (such as a wall outlet) before starting.

1. Remove all ornaments and decorations.
2. Gently lift off Top Section (A) and unplug the lights, then lift off Middle Section (B) **and unplug the lights, and finally remove the Bottom Section (C) from the tree stand.**
3. **Carefully place the tree and stand in its carton and tape shut.**

DISCLAIMER

PLEASE READ THE FOLLOWING CAREFULLY

THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS LIST AND ASSEMBLY DIAGRAM IN THIS MANUAL AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT, OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACEMENT PARTS THERETO.

Record Product's Serial Number Here: _____

Note: If product has no serial number, record month and year of purchase instead.

Note: Some parts are listed and shown for illustration purposes only and are not available individually as replacement parts.

The material in this manual is for informational purposes only. The product(s) it describes are subject to change without prior notice, due to the manufacturer's continuous development program. Barton makes no representations or warranties with respect to this manual or with respect to the products described herein. Barton shall not be liable for any damages, losses, costs or expenses, direct, indirect or incidental, consequential or special, arising out of, or related to the use of this material or the products described herein.

Questions, issues or missing parts?

Before returning to your retailer, our customer service team is here to help.



Call Us: 909.628.0880

Email Us: customer@bartonliving.com

Hours of Operation: 9am - 3pm PST Monday - Friday

MADE IN CHINA