

ARTIFICIAL CHRISTMAS WREATH AND GARLAND



93002 BLUE WREATH



93003 BLUE GARLAND



93004 BLUE FLOWER



93005 RED WREATH



93006 RED GARLAND



93007 RED FLOWER

OWNER'S MANUAL AND SAFETY INSTRUCTIONS

SAVE THIS MANUAL. KEEP THIS MANUAL FOR SAFETY WARNINGS, PRECAUTIONS, ASSEMBLY, OPERATION, INSPECTION, MAINTENANCE AND CLEANING PROCEDURES. WRITE THE PRODUCT'S SERIAL NUMBER ON THE BACK OF THE MANUAL, OR THE MONTH AND YEAR OF PURCHASE IF PRODUCT HAS NO SERIAL NUMBER

SAFETY INFORMATION




Read all safety warnings and instructions. Failure to follow the warnings and instructions may result in injury and/or property damage. Save all warnings and instructions for future reference.


The warning and safety instructions in this manual are not meant to cover all possible conditions and situations that may occur. Common sense, caution and care must be exercised when operating or cleaning tools and equipment. Always contact your dealer, distributor, service agent or manufacturer about problems or conditions you do not understand before operating the product.

- For Indoor or Sheltered Outdoor Use Only. Product may be used outdoors only where protected from failing rain, snow, or sleet and protected from the elements.
- Do not place near gas or electric heaters, radiators, fireplaces, candles, or other similar sources of heat or open flames.
- For best results, use 2x AA batteries (batteries not included).
- Install only new batteries of the same type in your product.
- Failure to insert batteries in the correct polarity, as indicated in the battery compartment, may shorten the life of the batteries or cause batteries to leak.
- Do not mix old and new batteries.
- Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium) or (Nickel Metal Hydride) batteries.
- Do not dispose of batteries in fire.
- Batteries should be recycled or disposed of as per state and local guidelines.
- Carry only by the jute rope.
- Always position wire leads so as not to cause a tripping hazard.
- When hanging, make sure the wall is stable and strong enough to hang.
- · Wipe clean with a dry cloth only.
- Recommended for indoor & covered porch use.


BATTERY INSTALLATION




Step 1: Find the battery box on the back of the wreath base, gently open the battery cover by sliding the cover in the direction of the arrow and lifting the cover upwards.



Step 2: Install 2x AA batteries (not included) matching the polarity shown inside the battery compartment.



Step 3: Replace the cover by sliding it into position until it latches.



Step 4: Switch Operations: Slide the switch to the ON position to turn the lights on. Slide the switch to the "TIMER" position to turn on the lights and put the unit in timer mode. Lights cycle 6 hours on and then 18 hours off for a complete 24 hour cycle. Slide the switch to the "OFF" position to turn the lights off.

DISCLAIMER

PLEASE READ THE FOLLOWING CAREFULLY

THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS LIST AND ASSEMBLY DIAGRAM IN THIS MANUAL AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER OR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS QUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT, OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS, AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACEMENT PARTS THERETO.

Record Product's Serial Number Here:	
Note: If product has no serial number, record month and year of purchase instea	ı.

Note: Some parts are listed and shown for illustration purposes only and are not available individually as replacement parts.

The material in this manual is for informational purposes only. The product(s) it describes are subject to change without prior notice, due to the manufacturer's continuous development program. Barton makes no representations or warranties with respect to this manual or with respect to the products described herein. Barton shall not be liable for any damages, losses, costs or expenses, direct, indirect or incidental, consequential or special, arising out of, or related to the use of this material or the products described herein.

Questions, issues or missing parts?

Before returning to your retailer, our customer service team is here to help.



Call Us: 909.628.0880

Email Us: customer@bartonliving.com

Hours of Operation: 9am - 3pm PST Monday - Friday

MADE IN CHINA